


LG


BX580-2011 Operation Manual

This LG Blu-Ray disc player has been modified to play discs from the following regions:

- Blu-ray regions A, B and C (Manually Switchable).
- DVD regions: Plays all DVD region 1-6 + regionfree (Manually Switchable).



DVD regions



Blu-ray regions

Switching between the regions is done using the original remote of the LG player. To change DVD regions **PRESS RED** button followed by key 1-6 for DVD-region 1-6, press key 0 for region-free DVD.



To change Blu-ray region **PRESS BLUE** button followed by key 1-3 for Blu-ray region A, B or C. To change Blu-Ray region, make sure your player is in stand-by. Press BLUE button B, followed by key 1-3 to set Blu-Ray region A, B or C. Press one key at a time. Holding blue key while pressing 1-3 will not work. Please also make sure that the quick start option in the player's setup menu is set to off.

